



Brenda Jo Jones David T. Jones
Cell: 610-960-6441 Cell: 610-960-6439
brendajo@hoofarmor.com david@hoofarmor.com

Hoof Armor Acres
153 Groff Road
Bechtelsville, PA 19505-9137

Quick Tips... Common Questions...

1. Hoof Armor is very liquid when it is dispensed from the tube. It comes out quickly.
2. You do not need to pull the trigger on the dispenser very hard for Hoof Armor to be dispensed.
3. Hoof Armor goes on very thinly. Like a varnish coat. Thicker **is not** better.
4. Hoof Armor is exothermic and does cure to the bottom of the hoof. It is not just a coating.
5. If Hoof Armor is applied too thickly it will not cure properly and will peel off.
6. If a second coat is desired it can be applied 24 hours after the first.
7. Once Hoof Armor is applied the talcum powder should be applied liberally so that it coats all the areas that Hoof Armor has been applied to. We recommend a horse should be in the pasture or stall for a couple of hours to let Hoof Armor cure.
8. Leave the last mix nozzle on the cartridge. Do not re-use the original cap.
9. If necessary, Hoof Armor can be reapplied during a long ride just by cleaning the hoof and reapplying.
10. Hoof Armor summer/winter application tip. Keep Hoof Armor cool in the summer and warm in the winter. Around 76°F is optimal.
11. Hoof Armor can be applied to the sole, frog (which is on the same plane as the sole), heel bulbs and up onto the front of the hoof to about where nail holes would be on a shod horse.
12. Hoof Armor goes on looking very shiny. That will change once the horse begins to travel. Please do not think it is not there! If you do not see hoof wear, then Hoof Armor is doing its job in protecting the hoof. Sometimes wetting the hoof will allow you to still see shiny spots.
13. How dry should my horse's feet be before applying Hoof Armor? If necessary, and the weather has been all rain, please keep the horse in a stall or enclosed area where it can stand in shavings or dry sand or dirt for 1-2 hours. Overnight, or for several hours, is optimal. Optionally, one can use a hair dryer to dry the hooves beforehand.

WE WOULD LOVE TO HEAR ABOUT YOUR EXPERIENCE WITH HOOF ARMOR!